# **AC Input Modules**

Please note: \$US prices shown For current \$AUD visit www.directautomation.com.au

### P3-16NA \$159.00

#### **AC Input**

The P3-16NA AC Input Module provides sixteen

100–240 VAC isolated inputs with four isolated commons.



We recommend using prewired **ZIP**Link cables and connection modules. See Wiring Solutions

Terminal block cover included. If you wish to hand-wire your module, a removable terminal block is sold separately. Order part number <u>P3-RTB</u>.

WARNING: EXPLOSION HAZARD — SUBSTITUTION OF COMPONENTS MAY IMPAIR SUITABILITY FOR CLASS I, DIVISION 2.



| Input Specifications       |      |  |  |  |
|----------------------------|------|--|--|--|
| Inputs per Module          |      | 16   |  |  |
| Operating Voltage Range    | CE   | 100-240 VAC (± 20%)  |  |  |
| (Tolerance)                | UL   | 100-240 VAC (± 20%)  |  |  |
| AC Frequency               |      | 47–63 Hz   |  |  |
| Input Current (Typical)    |      | 8.5 mA @ 100VAC (50Hz)<br>10mA @ 100VAC (60Hz)<br>17mA @ 240VAC (50Hz)<br>20mA @ 240VAC (60Hz) |  |  |
| Maximum Input Current @    | Temp | 26 mA @ 60° C (288VAC)   |  |  |
| Input Impedance            |      | 15kΩ (50Hz), 12kΩ (60Hz)   |  |  |
| ON Voltage Level           |      | > 70VAC  |  |  |
| OFF Voltage Level          |      | < 20VAC  |  |  |
| Minimum ON Current         |      | 5mA  |  |  |
| Maximum OFF Current        |      | 2mA  |  |  |
| OFF to ON Response         |      | < 10ms   |  |  |
| ON to OFF Response         |      | < 25ms   |  |  |
| Status Indicators          |      | Logic side (16 points)   |  |  |
| Terminal Type (not include | d)   | 20-position removable terminal block   |  |  |
| Commons                    |      | 4 Isolated (4 points / common)   |  |  |

| General Specifications        |  |  |  |
|-------------------------------|--|--|--|
| Operating Temperature         | 0°C-60°C (32°F-140°F),   |  |  |
| Storage Temperature           | -20°C-70°C (-4°F-158°F)  |  |  |
| Humidity                      | 5 to 95% (non-condensing)  |  |  |
| Environmental Air             | No corrosive gases permitted   |  |  |
| Vibration                     | IEC60068-2-6 (Test Fc)   |  |  |
| Shock                         | IEC60068-2-27 (Test Ea)  |  |  |
| Field to Logic Side Isolation | 1500VAC applied for 1 minute   |  |  |
| Insulation Resistance         | >10MΩ @ 500VDC   |  |  |
| Heat Dissipation              | 8.76 W   |  |  |
| Enclosure Type                | Open equipment   |  |  |
| Module Keying to Backplane    | Electronic   |  |  |
| Module Location               | Any I/O slot in any local, expansion, or remote base in a Productivity3000 system.   |  |  |
| Field Wiring                  | Removable terminal block (not included). Use <b>ZIP</b> Link wiring system or optional terminal block. See Wiring Solutions.   |  |  |
| Weight                        | 95g (3.35 oz)  |  |  |
| Agency Approvals              | UL508 file E157382, Canada & USA UL1604 file E200031, Canada & USA CE (EN61131-2*) This equipment is suitable for use in Class 1, Division 2, Groups A, B, C and D or non- hazardous locations only. |  |  |


 $\hbox{^*Meets EMC and Safety requirements. See the Declaration of Conformity for details.}$ 


| Remo  | Removable Terminal Block Specifications   |  |  |  |
|---|---|--|--|--|
| Description   | Part No. <u>P3-RTB</u> ; 20 screw terminals   |  |  |  |
| Wire Range  22–14 AWG (0.324 to 2.08 sq. mm) Solid / stranded conductor 3/64 in. (1.2 mm) insulation maximum USE COPPER CONDUCTORS, 60°C or equivalent. |   |  |  |  |
| Screw Driver<br>Width   | 1/4 inch (6.5 mm) maximum   |  |  |  |
| Screw Size M3 size  |   |  |  |  |
| Screw Torque  | Field terminals - 7–9 in·lb (0.882–1.02 N·m) Self-jacking screws - 2.7–3.6 in·lb (0.3–0.4 N·m). Do not overtighten screws when installing terminal block. |  |  |  |

# **AC Input Modules**

# P3-16NA (cont'd)

Wiring Diagrams







# Wiring Solutions

## Wiring Solutions using the **ZIP**Link wiring system

**ZIP**Links eliminate the normally tedious process of wiring between devices by utilizing prewired cables and DIN rail mount connector modules. It's as simple as plugging in a cable connector at either end or terminating wires at only one end. Prewired cables keep

installation clean and efficient, using half the space at a fraction of the cost of standard terminal blocks. There are several wiring solutions available when using the **ZIP**Link System ranging from

PLC I/O-to-**ZIP**Link Connector Modules that are ready for field termination, options for connecting to third party devices, GS, DuraPulse and SureServo Drives, and specialty relay, transorb and communications modules. Pre-printed I/O-specific adhesive label strips for quick marking of **ZIP**Link modules are provided with **ZIP**Link cables. See the following solutions to help determine the best **ZIP**Link system for your application.

# Solution 1: Productivity Series I/O Modules to ZIPLink Connector Modules

When looking for quick and easy I/O-to-field termination, a **ZIP**Link connector module used in conjunction with a prewired **ZIP**Link cable, consisting of an I/O terminal block at one end and a multi-pin connector at the other end, is the best solution.

Using the PLC I/O Modules to **ZIP**Link Connector Modules selector tables located in this section,

- 1. Locate your I/O module/PLC.
- 2. Select a **ZIP**Link Module.
- 3. Select a corresponding **ZIP**Link Cable.



# Solution 2: Productivity Series I/O Modules to ZIPLink Connector Modules

When wanting to connect I/O to another device within close proximity of the I/O modules, no extra terminal blocks are necessary when using the **ZIP**Link Pigtail Cables. **ZIP**Link Pigtail Cables are prewired to an I/O terminal block with color-coded pigtail with soldered-tip wires on the other end.

Using the I/O Modules to 3rd Party Devices selector tables located in this section,

- 1. Locate your PLC I/O module.
- 2. Select a **ZIP**Link Pigtail Cable that is compatible with your 3rd party device.



#### Solution 3: GS Series and DuraPulse Drives Communication Cables

Need to communicate via Modbus RTU to a drive or a network of drives?

**ZIP**Link cables are available in a wide range of configurations for connecting to PLCs and SureServo, SureStep, Stellar Soft Starter and AC drives. Add a **ZIP**Link communications module to quickly and easily set up a multidevice network.

Using the Drives Communication selector tables located in this section,

- 1. Locate your Drive and type of communications.
- 2. Select a **ZIP**Link cable and other associated hardware.





# Wiring Solutions

#### Solution 4: Serial Communications Cables

**ZIP**Link offers communications cables for use with DirectLOGIC, CLICK, and Productivity3000 CPUs, that can also be used with other communications devices. Connections include a 6-pin RJ12 or 9-pin, 15-pin and 25-pin D-sub connectors which can be used in conjunction with the RJ12 or D-Sub Feedthrough modules.

Using the Serial Communications Cables selector table located in this section,

- 1. Locate your connector type
- 2. Select a cable.



#### Solution 5: Specialty ZIPLink Modules

For additional application solutions, **ZIP**Link modules are available in a variety of configurations including stand-alone relays, 24VDC and 120VAC transorb modules, D-sub and RJ12 feedthrough modules, communication port adapter and distribution modules, and SureServo 50-pin I/O interface connection.

Using the **ZIP**Link Specialty Modules selector table located in this section,

- 1. Locate the type of application.
- 2. Select a **ZIP**Link module.



#### Solution 6: ZIPLink Connector Modules to 3rd Party Devices

If you need a way to connect your device to terminal blocks without all that wiring time, then our pigtail cables with color-coded soldered-tip wires are a good solution. Used in conjunction with any compatible **ZIP**Link Connector Modules, a pigtail cable keeps wiring clean and easy and reduces troubleshooting time.

Using the Universal Connector Modules and Pigtail Cables table located in this section,

- 1. Select module type.
- 2. Select the number of pins.
- 3. Select cable.





# CPU I/O Modules to ZIPLink Connector Modules - Productivity3000®

| Produ        | Productivity3000 CPU Input Module ZIPLink Selector |                      |                 |                                  |  |
|--------------|--|----------------------|-----------------|----------------------------------|--|
| CP           | U  |                      | ZIPLink         |                                  |  |
| Input Module | # of Terms   | Component            | Module Part No. | Cable Part No.                   |  |
| P3-08NAS     | 20   | Feedthrough          |                 | 71 D2 CD1 20 *                   |  |
| P3-08ND3S    | 20   | Feedthrough ZL-RTB20 |                 | ZL-P3-CBL20 *                    |  |
| P3-16NA      | 20   | Feedthrough          | ZL-RTB20        | ZL-P3-CBL20-1L<br>ZL-P3-CBL20-2L |  |
| P3-16ND3     | 20   | Feedthrough          |                 |                                  |  |
| P3-10NU3     | 20   | Sensor               | ZL-LTB16-24-1   | ZETO OBEZO ZE                    |  |
| P3-32ND3     | 40   | Feedthrough          | ZL-RTB40        |                                  |  |
| P3-32ND3     | 40   | Sensor               | ZL-LTB32-24-1   | ZL-CBL40<br>ZL-CBL40-1           |  |
| P3-64ND31    | 40   | Feedthrough          | ZL-RTB40        | ZL-CBL40-1<br>ZL-CBL40-2         |  |
| F 0-04ND01   | 40   | Sensor               | ZL-LTB32-24-1   |                                  |  |

| Productivity3000 CPU Analog In Module ZIPLink Selector |               |             |          |                                  |
|--|---------------|-------------|----------|----------------------------------|
| CP   | U             |             | ZIPLink  |                                  |
| Analog<br>Module                                       | # of Terms    | Component   | Module   | Cable                            |
| P3-04ADS   | 20            | Feedthrough |          |                                  |
| P3-08AD  | 20            | Feedthrough | ZI DTD20 | ZL-P3-CBL20                      |
| P3-16AD-1  | 20            | Feedthrough | ZL-RTB20 | ZL-P3-CBL20-1L                   |
| P3-16AD-2  | 20            | Feedthrough |          |                                  |
| <u>P3-08RTD</u> <sup>2</sup>                           | Matched Only  | See Note 2  |          |                                  |
| <u>P3-08THM</u> <sup>2</sup>                           | T/C Wire Only | See Note 2  |          |                                  |
| <u>P3-04DA</u>   | 20            | Feedthrough |          |                                  |
| P3-08DA-1  | 20            | Feedthrough |          |                                  |
| P3-08DA-2  | 20            | Feedthrough |          |                                  |
| P3-16DA-1  | 20            | Feedthrough | ZL-RTB20 | ZL-P3-CBL20-1L<br>ZL-P3-CBL20-2L |
| P3-16DA-2  | 20            | Feedthrough |          | ZL-F J-OBLZU-ZL                  |
| P3-8AD4DA-1  | 20            | Feedthrough |          |                                  |
| P3-8AD4DA-2  | 20            | Feedthrough |          |                                  |

| Productivity3000 CPU Specialty Module ZIPLink Selector |             |             |                 |                            |  |
|--|-------------|-------------|-----------------|----------------------------|--|
| CI   | CPU ZIPLink |             |                 |                            |  |
| Input<br>Module  | # of Terms  | Component   | Module Part No. | Cable Part No.             |  |
| P3-HSI   |             |             |                 | ZL-CBL40-S                 |  |
| P3-HSO   | 40          | Feedthrough | ZL-RTB40        | ZL-CBL40-1S<br>ZL-CBL40-2S |  |



Note: **ZIP**Link Connector Modules specifications follow the Compatibility Matrix tables. **ZIP**Link Cables specifications are at the end of this **ZIP**Link section.

| Productivity3000 CPU Output Module ZIPLink Selector |             |                           |                       |                          |
|---|-------------|---------------------------|-----------------------|--------------------------|
| CF  | CPU ZIPLink |                           |                       |                          |
| Output<br>Module                                    | # of Terms  | Component Module Part No. |                       | Cable Part No.           |
| P3-08TAS  | 20          | Feedthrough               |                       | ZL-P3-CBL20 *            |
| P3-08TD1S   | 20          | Feedthrough               |                       | ZL-P3-CBL20-1L           |
| P3-08TD2S   | 20          | Feedthrough               |                       | ZL-P3-CBL20-2L           |
| P3-08TRS  | 20          | Feedthrough               | ZL-RTB20              |                          |
| P3-16TA   | 20          | Feedthrough               |                       |                          |
| F 3-101A  | 20          | Fuse                      |                       |                          |
|   |             | Feedthrough               |                       |                          |
| P3-16TD1  | 20          | Fuse                      | ZL-RFU20 <sup>4</sup> |                          |
|   |             | Relay (sinking)           | ZL-RRL16-24-1         | ZL-P3-CBL20              |
|   | 20          | Feedthrough               | ZL-RTB20              | ZL-P3-CBL20-1            |
| P3-16TD2  |             | Fuse                      | ZL-RFU20 <sup>4</sup> | ZL-P3-CBL20-2            |
|   |             | Relay (sourcing)          | ZL-RRL16-24-2         |                          |
| P3-16TR   | 20          | Feedthrough               | ZL-RTB20              |                          |
| 7 0-101N  | 20          | Fuse                      | ZL-RFU20 <sup>4</sup> |                          |
| P3-08TRS-1 <sup>3</sup>                             | 20          | Feedthrough               | ZL-RTB20              |                          |
| <u> </u>  | 20          | Fuse                      | ZL-RFU20 <sup>4</sup> |                          |
| P3-32TD1  | 40          | Feedthrough               | ZL-RTB40              |                          |
| 10-02101  | 40          | Fuse                      | ZL-RFU40 <sup>4</sup> |                          |
| P3-32TD2  | 40          | Feedthrough               | ZL-RTB40              |                          |
| 10-02102  | 40          | Fuse                      | ZL-RFU40 <sup>4</sup> | ZL-CBL40<br>ZL-CBL40-1   |
| P3-64TD1 <sup>1</sup>                               | 40          | Feedthrough               | ZL-RTB40              | ZL-CBL40-1<br>ZL-CBL40-2 |
| 10-04101  | 70          | Fuse                      | ZL-RFU40 <sup>4</sup> |                          |
| P3-64TD2 <sup>1</sup>                               | 40          | Feedthrough               | ZL-RTB40              |                          |
| <u> </u>  | 40          | Fuse                      | ZL-RFU40 <sup>4</sup> |                          |

- \* Select the cable length by replacing the \* with: Blank = 0.5m, -1 = 1.0m,
- 1 The P3-64ND3, P3-64TD1 and P3-64TD2 modules have two 32-point connectors and require two ZIPLink cables and two ZIPLink connector modules.
- 2 These modules are not supported by the ZIPLink wiring system.
- 3 The P3-08TRS-1 output module is derated not to exceed 2A per point maxiumum when used with the ZIPLink wiring system.
- 4 Note: Fuses (5 x 20 mm) are not included. See Edison Electronic Fuse section for (5 x 20 mm) fuse. S500 and GMA electronic circuit protection for fast-acting maximum protection. S506 and GMC electronic circuit protection for time-delay performance, Ideal for inductive circuits.

To ensure proper operation, do not exceed the voltage and current rating of ZIPLink module. ZL-RFU20 = 2A per circuit; ZL-RFU40 = 400 mA per circuit.



# I/O Modules

A variety of discrete, analog and specialty I/O modules are available for use in local, expansion, and remote I/O bases. Specifications for each module are on the following pages.

A filler module is available for unused I/O module slots (part number <u>P3-FILL</u>).

## **Discrete Input Modules**

| Productivity3000 Discrete Input Modules |  |                                    |          |  |
|---|--|------------------------------------|----------|--|
| Part Number                             | Part Number   Number of Inputs   Description |                                    | Price    |  |
| P3-16SIM                                | 16   | Input Simulator Module             | \$197.00 |  |
| P3-08ND3S                               | 8  | Isolated Sinking/Sourcing DC Input | \$99.00  |  |
| P3-16ND3                                | 16   | Sinking/Sourcing DC Input          | \$152.00 |  |
| P3-32ND3                                | 32   | Sinking/Sourcing DC Input          | \$208.00 |  |
| P3-64ND3                                | 64   | Sinking/Sourcing DC Input          | \$260.00 |  |
| P3-08NAS                                | 8  | Isolated AC Input                  | \$126.00 |  |
| P3-16NA                                 | 16   | AC Input                           | \$159.00 |  |

<sup>\*</sup>ZIPLink required.

## **Analog I/O Modules**

| Productivity3000 Analog Input Modules |       |                           |          |  |
|---------------------------------------|-------|---------------------------|----------|--|
| Part Number                           | Price |                           |          |  |
| P3-04ADS                              | 4     | Isolated Analog Input     | \$724.00 |  |
| P3-08AD                               | 8     | Analog Input              | \$393.00 |  |
| P3-16AD-1                             | 16    | Analog Input (Current)    | \$535.00 |  |
| P3-16AD-2                             | 16    | Analog Input (Voltage)    | \$524.00 |  |
| P3-08RTD                              | 8     | Analog RTD Input          | \$581.00 |  |
| P3-08THM                              | 8     | Analog Thermocouple Input | \$736.00 |  |

| Productivity3000 Analog Output Modules |                                     |                         |          |  |
|--|-------------------------------------|-------------------------|----------|--|
| Part Number                            | Part Number of Channels Description |                         | Price    |  |
| P3-04DA                                | 4                                   | Analog Output           | \$449.00 |  |
| P3-08DA-1                              | 8                                   | Analog Output (Current) | \$779.00 |  |
| P3-08DA-2                              | 8                                   | Analog Output (Voltage) | \$725.00 |  |
| P3-16DA-1                              | 16                                  | Analog Output (Current) | \$929.00 |  |
| P3-16DA-2                              | 16                                  | Analog Output (Voltage) | \$911.00 |  |

| Productivity3000 Analog Input/Output Modules |     |                               |          |  |
|--|-----|-------------------------------|----------|--|
| Part Number of Channels Description Price    |     |                               |          |  |
| P3-8AD4DA-1                                  | 8/4 | Analog Input/Output (Current) | \$598.00 |  |
| P3-8AD4DA-2                                  | 8/4 | Analog Input/Output (Voltage) | \$617.00 |  |

## **Specialty Modules**

| Productivity3000 Specialty Modules        |                             |                              |          |  |  |
|---|-----------------------------|------------------------------|----------|--|--|
| Part Number Of Channels Description Price |                             |                              |          |  |  |
| P3-HSI                                    | 2                           | High-Speed Pulse Input       | \$563.00 |  |  |
| P3-HS0*                                   | P3-HS0* 2 High-Speed Output |                              |          |  |  |
| P3-SCM                                    | 4 ports                     | Serial Communications Module | \$475.00 |  |  |

<sup>\*</sup>ZIPLink required.

## **Discrete Output Modules**

| Productivity3000 Discrete Output Modules |                      |                          |          |
|--|----------------------|--------------------------|----------|
| Part Number                              | Number of<br>Outputs | Description              | Price    |
| P3-08TD1S                                | 8                    | Isolated Sinking Output  | \$135.00 |
| P3-08TD2S                                | 8                    | Isolated Sourcing Output | \$141.00 |
| P3-16TD1                                 | 16                   | Sinking Output           | \$162.00 |
| P3-16TD2                                 | 16                   | Sourcing Output          | \$167.00 |
| P3-32TD1*                                | 32                   | Sinking Output           | \$208.00 |
| P3-32TD2*                                | 32                   | Sourcing Output          | \$208.00 |
| P3-64TD1*                                | *64                  | Sinking Output           | \$280.00 |
| P3-64TD2*                                | *64                  | Sourcing Output          | \$265.00 |
| P3-08TAS                                 | 8                    | Isolated AC Output       | \$177.00 |
| P3-16TA                                  | 16                   | AC Output                | \$210.00 |
| P3-08TRS                                 | 8                    | Isolated Relay Output    | \$159.00 |
| P3-08TRS-1                               | 8                    | Isolated Relay Output    | \$194.00 |
| P3-16TR                                  | 16                   | Relay Output             | \$177.00 |

\*ZIPLink required.


#### **Module Installation Procedure**



WARNING: DO NOT APPLY FIELD POWER UNTIL THE FOLLOWING STEPS ARE COMPLETED. SEE HOT-SWAPPING PROCEDURE FOR EXCEPTIONS.


**Step One:** Align circuit card with slot and press firmly to seat module into connector.

**Step Two:** Pull top and bottom locking tabs toward module face. Click indicates lock is engaged.



**Step Three:** Attach field wiring using optional terminal block or **ZIP**Link wiring system and install cover.







**WARNING:** EXPLOSION HAZARD – DO NOT CONNECT OR DISCONNECT CONNECTORS OR OPERATE SWITCHES WHILE CIRCUIT IS LIVE UNLESS THE AREA IS KNOWN TO BE NON-HAZARDOUS. DO NOT HOT-SWAP MODULES UNLESS THE AREA IS KNOWN TO BE NON-HAZARDOUS.